



WAREHOUSE MATRIX

A.B.N 29 764 742 043

PO Box 24
Balaklava SA 5461

Telephone 08 8862 2078
Facsimile 08 8862 2033

TECHNICAL INFORMATION

WAXED FLOOR STRIP PROCEEDURE

For the removal of old discoloured built up wax from sealed timber or parquetry flooring.

EQUIPMENT

Wet Floor Sign
Old Mop and plastic bucket for solution application
Clean Mop and wringer bucket for rinse water
Wet pick up vacuum, if no vacuum available, extra mops and buckets will be required.
Recommended All Purpose Stripper
16" Polishing machine fitted with instaloc or Velcro drive disk
16" (40cm) Red pads
16" (40cm) Black pads
Edge pad holder and brown strip pad
Polish tray
Polish applicator
Hand and feet protection

Note - The area to be stripped should be broken into a workable area or a pattern during the stripping procedure.

METHOD - ENSURE ADEQUATE VENTILATION

PROTECT CARPET AREAS AROUND FLOOR FROM MACHINE SPRAY

1. Place Wet Floor sign in visible position.
2. Apply Recommended All Purpose Stripper at the recommended dilution rate to the area of floor to be stripped, allow to stand for 2-3 minutes, agitate with a brush or similar and pick up slurry.
3. Rinse the entire floor area with clean water, ensure that the floor is rinsed clear.
4. When the floor is dry, using a BLACK pad, buff the floor area with the polishing machine, turning and replacing pads as required.
5. Apply a coat of Recommended Solvent Based Wax Floor Polish" to the entire floor area. Allow time to dry.
6. When the floor is dry, using a RED pad, buff the floor area with the polishing machine, turning and replacing pads as required.
7. Apply a further coat of Recommended Solvent Based Wax Floor Polish" to the floor area.
8. Rebuff the floor as in para 5.
9. To clean the red or black pads after use, wash in hot water **OR** in solution of stripper, **RINSE CLEAN** and dry.



Main Office: 27 Gwy Terrace, Balaklava SA 5461
Email: info@warehousematrix.com.au